

FIX KIT REQUEST FORM

These are the 4 different versions of Finsterwalder male buckles affected by their safety note.

Please tick the buckle that is on your lcaro harness:



HARNESS SERIAL NUMBER HARNESS DETAIL MODEL SIZE IMPORTER'S NAME DEALER'S NAME PLEASE SHIP MY FIX KIT TO THE FOLLOWING ADDRESS NAME STREET NAME AND NUMBER ZIP CODE

Please send us the completed form via email and transfer the amount of 10,-€ to bank account below.

COUNTRY

Payment reference: "Finsterwalder Kit" and your Name

CITY

PHONE NUMBER



How to REPLACE the Finsterwalder faulty BUCKLES on your Icaro harness with T-LOCK strap system



This is how you REPLACE the SAFE-T STRAP connected to one of the leg straps.

Before proceeding, make sure the buckles of the provided kit are the same as the ones on your harness.



Cut the loop of the safe-T strap without damaging the leg strap.



TAKE THE NEW SAFE-T STRAP provided by Icaro





PASS THE BUCKLE of the leg strap

THROUGH THE LOOP of the new safeT strap.



POSITION the leg strap at the VERY
END OF THE new safe-T strap LOOP
and then BEND THE SHORT VELCRO
BIT OVER the new safe-T strap.



BEND THE LONG VELCRO BIT OVER
the short one so that the leg strap is
HELD FIRMLY at the very END OF THE
new safe-T strap LOOP.



TURN THE ELASTIC SHEATH INSIDE

OUT and PLACE IT OVER THE VELCRO

to secure the new safe-T strap.